



Volvo Trucks. Driving Progress

VOLVO SELECTED

Selected used trucks with Volvo Driveline Warranty



Volvo Selected is high-quality trucks that are safe, proven and characterised by good service history.

A Volvo Selected truck is always less than three years old and comes with limited mileage. It has been meticulously inspected to secure the same built-in performance as a brand new truck, so you can rest assured that it's a wise choice on the used truck market. To make it an even safer purchase, Volvo Selected offers optional maintenance contracts to ensure uptime. In essence the vehicle will be in peak condition when you take ownership and ready to deliver trusted service for many years.

More uptime with our driveline warranty

Volvo Selected includes a 6 month, 90 000km driveline warranty. The driveline warranty covers failures on engine, cooling system, transmission and drive units. Warranty only applicable if serviced at an approved Volvo Trucks dealer.

This is Volvo Selected:

- Under 36 months old
- Less than 500 000km
- 6 Month Volvo Driveline Warranty
- Optional maintenance contract
- Next due service Completed
- 80 point pre delivery inspection
- Full cosmetic check
- All tyres minimum 7mm
- Spare wheel
- Spare key
- Full service history
- Professional valet

VOLVO

Volvo Trucks Southern Africa

www.volvotrucks.co.za



VOLVO SELECTED

Quality-assured used trucks with driveline coverage

Greater peace of mind with our Volvo Driveline Warranty

Items covered under your Volvo Used Trucks Driveline Warranty

The Volvo Used Trucks Driveline Warranty covers you for sudden and unforeseen failure of specific parts or components, it does not cover fair wear and tear. This policy is not transferable. **90 000 km mileage limit for 6 months.**

Engine and cooling system

- Cylinder head and block
- Cylinder liner and seals
- Pistons
- Crank mechanism
- Connecting rods and bearings
- Camshaft
- Valve mechanism and valve cover
- Timing mechanism
- Oil pump and oil cooler
- Engine sump
- Fuel pump
- Injection pump
- Unit injectors and injector sleeves
- Inlet and exhaust manifolds
- Turbo charger
- Turbo compound
- Volvo engine brake/exhaust brake
- Coolant pump
- Cooling fan
- Expansion tank
- Radiator
- Intercooler
- Air conditioning condenser
- Electric air pre-heater
- Engine ECU
- Flywheel housing
- PTO housing (engine)

EXCLUDING all other parts associated with the engine including mountings, sensors, seals and wiring looms. (Please note damage caused by fuel contamination is excluded).

* Full terms and conditions apply and are available on application.

Transmission

- Gearbox casing
- Selector forks and shafts
- Synchronizing parts
- Gears, bearings and shafts
- Oil pump and oil cooler
- Gear selector and ECU

EXCLUDING all other parts associated with the transmission including clutch, clutch release bearing, external linkages, sensors, seals and wiring looms.

Clutch

- Clutch friction plate
- Clutch pressure plate
- Clutch release cylinder
- Clutch release bearing
- Clutch release cylinder PWM valve

EXCLUDING all other parts associated with the clutch including external linkages, sensors, seals and wiring looms.

Drive unit

- Drive shafts
- Differential unit gears
- Propshaft/support bearing
- Hub reduction gears
- Differential lock gear/selector
- Differential unit casing

EXCLUDING all other parts associated with the drive unit including external linkages, solenoids, electrics, sensors, seals and wiring looms.

Steering

- Steering pump/pipe work
- Steering box

EXCLUDING all external linkages, joints, rubber boots, gaiters and external oil leaks.

Electrical

- Starter motor
- Alternator
- Wiper motor
- Relays
- Vehicle ECU
- Vehicle master control unit
- Human-machine interface control unit
- Night heater
- Light control module
- Instrument cluster
- Tachograph head
- Accelerator potentiometer
- Cruise control

EXCLUDING all other parts associated with the electrical system including lighting systems, direction indicator stalk, wiring looms, fuse boxes, gauges and sensors.

Braking system

- Compressor
- Brake ABS/EBS control unit
- Air dryer
- Air production modulator
- Engine brake valve
- Brake calipers
- Valves and valve blocks
- Brake chambers
- EBS system Inc. control unit and speed sensors

EXCLUDING all other parts associated with the braking system including brake pad wear sensors and wiring looms.

NOTE: As with all components covered under this warranty, it is for sudden and unforeseen failure only. It does not cover fair wear and tear. Full terms and conditions apply and are available on application.

VOLVO

Volvo Trucks Southern Africa

www.volvotrucks.co.za